

REVOLUTIONARY ADJUSTABLE TENSION
SELF-CLOSING GATE HINGE
INSTALLATION INSTRUCTIONS



/// Increase -Tension

Important !
Adjust clockwise only!

- ONE tension click per hinge at the time
- After each adjustment check for desired gate tension
- Equal amount of tension clicks per hinge if possible.
- Maximum FOUR tension clicks per hinge.



/// Release -Tension

Insert Tool

Push to reset tension

Safetech Global – Limited Lifetime Warranty
[this "Warranty"]

1. Subject to the conditions and limitations set out below, Safetech Global ["Safetech"], warrants that, for so long as the original purchaser of a product manufactured by Safetech owns that product (the "Product"), the Product will be free from all defects due to faulty design, materials or workmanship.
2. This Warranty is personal to the original purchaser of the Product, or to the first consumer where the Product has been purchased and installed by a contractor for the consumer's benefit, and is not transferable.
3. This Warranty does not apply in respect of defects due to or arising from:
 - (a) normal wear and tear;
 - (b) the failure to follow any procedures specified or recommended by Safetech for the installation, operation and maintenance of the Product;
 - (c) any act or circumstance beyond Safetech's control including tampering, unauthorised repairs or modifications, misuse, abuse, accident, damage in transit, damage caused by animals or natural events;
 - (d) any defect of or in any material to which the Product is attached; or
 - (e) the faulty workmanship of any person other than Safetech, including the installer of the Product.
4. To claim under this Warranty:
 - (a) the purchaser must advise Safetech within 14 days of discovering a defect in the Product; and
 - (b) the purchaser must return the defective Product to Safetech or its agent, freight prepaid, together with proof of purchase.
5. Safetech will not, under this Warranty, be responsible for consequential damages (such as loss of use) inconvenience, loss or damage to personal property, whether direct, indirect or economic and whether arising in contract or tort. Under this Warranty Safetech's responsibility shall not exceed the purchase price of the component or its replacement.
6. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
7. Where a failure does not amount to a major failure, Safetech will provide, at Safetech's option a repair, replacement or refund for the hardware component of. If a product or component is no longer available and cannot be repaired, Safetech will, in its absolute discretion, replace the product with a substitute item.
8. The benefits to the purchaser given by this manufacturer's Warranty are in addition to all rights and remedies conveyed by the Competition and Consumer Act 2010 (Commonwealth) and any other statutory rights to which the purchaser may already be entitled, and this Warranty does not exclude, restrict or modify any such rights or remedies implied by law.
9. No other express warranty or representation has been made or will be made on behalf of Safetech with respect to its hardware components, or the operation, repair or replacement of those components. No representative of Safetech or its distributors or retailers are authorised to make any changes or modifications to this Warranty.

This Warranty is provided by Safetech Global.

TOPKLIK 

MEGAKLIK 

SAFETECH 

safetechgl.com

Ph: +852 31026829

HINGE MAINTENANCE CHECKLIST

Regular maintenance must be undertaken every 6 months to ensure the safe operation of gate hinges including:

1. Check gate is opening & closing smoothly and swinging freely
2. Check all visible moving parts to ensure hinge has no debris impeding its operation
3. Check all screws are tightly fitted and there is no screw movement during operation of the hinge
4. Test closing mechanism to ensure sufficient tension to close the gate from various distances at 10 mm increments. Adjustable tension hinges can be adjusted with the allen key provided (fixed tension hinge requires adjustment by fence installer)
5. Check safety cap is fitted securely